





Installation instructions Roxtec C ComShelt™ kits

Content of kits


Components	C ComShelt™ kit/18	C ComShelt™ kit/12 with cover plate	C ComShelt™ Expansion module kit/6
 Roxtec C ComShelt™ frame	1 pc.	1 pc.	–
 Roxtec C stayplate	4 pcs.	3 pcs.	1 pc.
 Roxtec CM 40 10-32 module	12 pcs.	6 pcs.	6 pcs.
 Roxtec CM 20w40 module	3 pcs.	3 pcs.	–
 Screw ST 4.8x19 Z-Ni	14 pcs.	14 pcs.	–
 Roxtec Assembly Gel	1 pc.	1 pc.	1 pc.
 Roxtec cover plate	–	1 pc.	–




Aperture dimensions




Installation of ComShelt™ kit/18




Attach to wall using screws or rivets. Recommended screw dim. ST 4.8 (included in C ComShelt kit).




Make sure that all inside surfaces of the frame are free from dust or dirt.




Lubricate the inside faces of the frame with Roxtec Assembly Gel. Make sure to put gel into the corners.




Adapt modules which are to hold cables or pipes by peeling off layers. The halves may not differ by more than one layer.




Achieve a 0.1–1 mm gap between the two halves when held against the cable/pipe.




Lubricate the modules thoroughly with Roxtec Assembly Gel, both the inside and outside faces.




Insert the modules according to your transit plan. Start with the largest modules.



Insert a stayplate on top of every finished row of modules.




Before inserting the two final rows of modules, insert two stayplates.




Insert the two remaining rows of modules. Make sure that there is one stayplate between every row of modules.

Note: There shall be no stayplate between the last row of modules and the built-in compression unit.




Tighten the screws alternately on the compression unit.




The seal is compressed when the words "COMPRESSION OK" are **completely** visible under the screws of the compression unit.

Installation C ComShell kit with cover plate




For complete installation, see step 1 - 8 on previous page.




Lubricate the cover plate all around except front and back with Roxtec Assembly Gel.



Make sure there is a stayplate between the last row of modules and the cover plate. Insert the cover plate with the bottom part facing the stayplate.




Tighten the screws alternately on the compression unit.




The seal is compressed when the words "COMPRESSION OK" are **completely** visible under the screws of the compression unit.


Replacing the cover plate with the Expansion module kit/6




Release the compression by loosening the two screws of the compression unit alternately.




Remove the cover plate from the transit.




Make sure that the inside surfaces are free from dust or dirt and have enough assembly gel before installing the Expansion module kit/6.




Insert the stayplate from the Expansion module kit/6.




Adapt modules which are to hold cables or pipes by peeling off layers. The halves may not differ by more than one layer.




Achieve a 0.1–1 mm gap between the two halves when held against the cable/pipe.




Lubricate the modules thoroughly with Roxtec Assembly Gel, both the inside and outside faces.



Insert the modules from the Expansion module kit/6 along with cables. Make sure that the stayplate from the expansion kit is between the two rows of modules.
Note: There shall be no stayplate between the last row of modules and the built-in compression unit.



Tighten the screws alternately on the compression unit.



The seal is compressed when the words "COMPRESSION OK" are **completely** visible under the screws of the compression unit.

Disassembly

Reverse order.

Note

- Cables shall go straight through the seal.
- To be used with CM modules.

DISCLAIMER

"The Roxtec cable entry sealing system ("the Roxtec system") is a modular-based system of sealing products consisting of different components. Each and every one of the components is necessary for the best performance of the Roxtec system. The Roxtec system has been certified to resist a number of different hazards. Any such certification, and the ability of the Roxtec system to resist such hazards, is dependent on all components that are installed as a part of the Roxtec system. Thus, the certification is not valid and does not apply unless all components installed as part of the Roxtec system are manufactured by or under license from Roxtec ("authorized manufacturer"). Roxtec gives no performance guarantee with respect to the Roxtec system, unless (I) all components installed as part of the Roxtec system are manufactured by an authorized manufacturer and (II) the purchaser is in compliance with (a), and (b), below.

(a) During storage, the Roxtec system or part thereof, shall be kept indoors in its original packaging at room temperature.

(b) Installation shall be carried out in accordance with Roxtec installation instructions in effect from time to time.

The product information provided by Roxtec does not release the purchaser of the

Roxtec system, or part thereof, from the obligation to independently determine the suitability of the products for the intended process, installation and/or use. Roxtec gives no guarantee for the Roxtec system or any part thereof and assumes no liability for any loss or damage whatsoever, whether direct, indirect, consequential, loss of profit or otherwise, occurred or caused by the Roxtec systems or installations containing components not manufactured by an authorized manufacturer and/or occurred or caused by the use of the Roxtec system in a manner or for an application other than for which the Roxtec system was designed or intended.

Roxtec expressly excludes any implied warranties of merchantability and fitness for a particular purpose and all other express or implied representations and warranties provided by statute or common law. User determines suitability of the Roxtec system for intended use and assumes all risk and liability in connection therewith. In no event shall Roxtec be liable for indirect, consequential, punitive, special, exemplary or incidental damages or losses."



Roxtec International AB
 Box 540, 371 23 Karlskrona, SWEDEN
 PHONE +46 455 36 67 00, FAX +46 455 820 12
 EMAIL info@roxtec.com, www.roxtec.com