




Bague de transition Roxtec Sleev-it™

Bague de protection contre les incendies pour raccords entre tuyauteries en acier et tuyauteries en plastique.

La bague de transition Roxtec Sleev-it™ assure une protection sans soudure contre les incendies pour les raccords entre tuyauteries acier et plastique de différentes tailles. Le collier en acier inoxydable s'installe facilement autour du joint entre les tuyauteries et contient un matériau intumescent qui réagit à la chaleur pour protéger le passage en cas d'incendie. Le collier s'utilise en environnement non pressurisé dans les nouvelles constructions comme dans les projets de rénovation.

- Léger
- Idéal pour la rénovation
- Installation facile et rapide



Caractéristiques du produit



Coupe-feu

Structure d'installation



Métal

Type de fixation



Boulonnage

Classements et certificats

Feu

- CLASSE A conformément au code FTP IMO 2010
- CLASSE B conformément au code FTP IMO 2010

Éléments d'étanchéité

Éléments d'étanchéité



Bague de transition Sleev-it™

Pour plus d'informations, veuillez consulter [roxtec.com](https://www.roxtec.com).



Kits de passage préconfigurés

mm/kg



SLEEVE-IT
TR-MAR50/50



SLEEVE-IT TR-MAR75/75



SLEEVE-IT
TR-MAR50/60 (2")



SLEEVE-IT TR-MAR75/90
(3")



SLEEVE-IT
TR-MAR90/90

Titre	Configuration	Dimensions d'ouverture Ø	Poids	N° art.
SLEEVE-IT TR-MAR50/50		0 - 0	0.44	106289
SLEEVE-IT TR-MAR75/75		0 - 0	0.7	106298
SLEEVE-IT TR-MAR50/60 (2")		0 - 0	0.5	106304
SLEEVE-IT TR-MAR75/90 (3")		0 - 0	0.7	106307
SLEEVE-IT TR-MAR90/90		0 - 0	0.7	106310

The product information provided by Roxtec does not release the purchaser of the Roxtec system, or part thereof, from the obligation to independently determine the suitability of the products for the intended process, installation and/or use.

Roxtec gives no guarantee for the Roxtec system or any part thereof and assumes no liability for any loss or damage whatsoever, whether direct, indirect, consequential, loss of profit or otherwise, occurred or caused by the Roxtec systems or installations containing components not manufactured by an authorized manufacturer and/or occurred or caused by the use of the Roxtec system in a manner or for an application other than for which the Roxtec system was designed or intended.

Roxtec expressly excludes any implied warranties of merchantability and fitness for a particular purpose and all other express or implied representations and warranties provided by statute or common law. User determines suitability of the Roxtec system for intended use and assumes all risk and liability in connection therewith. In no event shall Roxtec be liable for indirect, consequential, punitive, special, exemplary or incidental damages or losses.

The Roxtec products are offered and sold in accordance with the conditions of the Roxtec General Terms of Sales. The latest version of the Roxtec General Terms of Sales can be downloaded from <https://www.roxtec.com/en/about-us/about-roxtec/general-terms-of-sales/>

We reserve the right to make changes to the product and technical information without further notice. Any errors in print or entry are no claims for indemnity. The content of this publication is the property of Roxtec International AB and is protected by copyright.

This document was generated on: 2024-04-05