




# Roxtec Sleev-it™ overgangskraag

Brandbeschermingskraag voor verbindingen tussen stalen en kunststof leidingen.

De Roxtec Sleev-it™ overgangskraag verzekert brandbescherming zonder lassen voor verbindingen tussen stalen en kunststof leidingen van verschillende diameters. De roestvrijstalen mantel wikkelt zich probleemloos om de verbinding tussen de leidingen en bevat uitzettend materiaal dat reageert op de hitte om de overgang te beschermen in geval van brand. De kraag wordt gebruikt in niet onder druk staande systemen in zowel nieuwbouw als retrofitprojecten.

- Lichtgewicht
- Ideaal voor retrofittoepassingen
- Snel en eenvoudig te installeren



## Producteigenschappen



Brandvertragend

## Installatiestructuur



Metaal

## Montagetype



Bouten

## Specificaties en certificaten

### Brand

- A-KLASSE volgens IMO 2010 FTP-code
- B-KLASSE volgens IMO 2010 FTP-code

## Gegevens van afdichtcomponenten

### Afdichtcomponenten



Sleev-it™ overgangskraag

Ga naar [roxtec.com](https://www.roxtec.com) voor uitgebreide informatie.



# Vooraf geconfigureerde doorvoersets

mm/kg



SLEEVE-IT  
TR-MAR50/50



SLEEVE-IT TR-MAR75/75



SLEEVE-IT  
TR-MAR50/60 (2")



SLEEVE-IT TR-MAR75/90  
(3")



SLEEVE-IT  
TR-MAR90/90

Titel	Configuratie	Afmetingen opening Ø	Gewicht	Art. nr.
SLEEVE-IT TR-MAR50/50		0 - 0	0.44	106289
SLEEVE-IT TR-MAR75/75		0 - 0	0.7	106298
SLEEVE-IT TR-MAR50/60 (2")		0 - 0	0.5	106304
SLEEVE-IT TR-MAR75/90 (3")		0 - 0	0.7	106307
SLEEVE-IT TR-MAR90/90		0 - 0	0.7	106310

The product information provided by Roxtec does not release the purchaser of the Roxtec system, or part thereof, from the obligation to independently determine the suitability of the products for the intended process, installation and/or use.

Roxtec gives no guarantee for the Roxtec system or any part thereof and assumes no liability for any loss or damage whatsoever, whether direct, indirect, consequential, loss of profit or otherwise, occurred or caused by the Roxtec systems or installations containing components not manufactured by an authorized manufacturer and/or occurred or caused by the use of the Roxtec system in a manner or for an application other than for which the Roxtec system was designed or intended.

Roxtec expressly excludes any implied warranties of merchantability and fitness for a particular purpose and all other express or implied representations and warranties provided by statute or common law. User determines suitability of the Roxtec system for intended use and assumes all risk and liability in connection therewith. In no event shall Roxtec be liable for indirect, consequential, punitive, special, exemplary or incidental damages or losses.

The Roxtec products are offered and sold in accordance with the conditions of the Roxtec General Terms of Sales. The latest version of the Roxtec General Terms of Sales can be downloaded from <https://www.roxtec.com/en/about-us/about-roxtec/general-terms-of-sales/>

We reserve the right to make changes to the product and technical information without further notice. Any errors in print or entry are no claims for indemnity. The content of this publication is the property of Roxtec International AB and is protected by copyright.

This document was generated on: 2024-04-05