



Installation instructions Roxtec KFO frame



Components



- A. Roxtec KFO frames
- B. Gasket
- C. Fasteners
- D. Roxtec Lubricant

Additional information




Scan QR code or visit roxtec.com for additional information such as drawings, aperture, videos, ratings and certificates.




Tools

- Allen key (not included)


Installation




Make or verify an aperture.
Structure thickness shall be 5 - 8 mm.




Divide the frame into two frame parts.




Lubricate all end surfaces of the frame parts with any Roxtec Lubricant.




If cables are pre-routed, reconnect the frame parts around the cables. Hexagonal bolt holes (A) must point outwards, away from the wall structure.




If cables are pre-routed, you will have to cut the gasket in a 45° angle, on the short side, to be able to mount it.




Lay the frame with the un recessed holes upward.




Remove the protection foil from the gasket.



Attach the adhesive gasket on the frame side with the round holes, which should face the structure.



Place the frame with the gasket side against the wall and insert all bolts and nuts. Hexagonal bolt holes (A) must point outwards, away from the wall structure.



Insert and tighten all the bolts to 7 Nm.




Check additional documentation, if applicable.

After installation inspection


- Are all screws tightened correctly?
- Is the gasket positioned correctly?

Installation of larger frames using mid section


A frame equipped with a mid section will not meet the requirement for UL certification.




Lubricate all end surfaces of the frame parts with any Roxtec Lubricant.




Assemble the parts.




Assembled frame.




Lay the frame with the un-recessed holes upward.




Remove the protection foil from the gasket.



Attach the adhesive gasket parts on the frame side with the round holes, which should face the structure.



Place the frame with the gasket side against the wall and insert all bolts and nuts. Hexagonal bolt holes (A) must point outwards, away from the wall structure.



Tighten the screws crosswise in small steps to 7 Nm.

Note

- To be used with RM components.
- Approvals or certificates may include amendments or limitations related to this application.
- The latest version of this and related documents are found at roxtec.com.

Disclaimer

*The Roxtec cable and pipe entry sealing system ('the Roxtec system') is a modular-based system of sealing products consisting of different components. Each and every one of the components is necessary for the best performance of the Roxtec system. The Roxtec system has been certified to resist a number of different hazards. Any such certification, and the ability of the Roxtec system to resist such hazards, is dependent on all components that are installed as a part of the Roxtec system. Thus, the certification is not valid and does not apply unless all components installed as part of the Roxtec system are manufactured by or under license from Roxtec ('authorized manufacturer'). Roxtec gives no performance guarantee with respect to the Roxtec system, unless (I) all components installed as part of the Roxtec system are manufactured by an authorized manufacturer and (II) the purchaser is in compliance with (a), and (b), below.

(a) During storage, the Roxtec system or part thereof, shall be kept indoors in its original packaging at room temperature.

(b) Installation shall be carried out in accordance with Roxtec installation instructions in effect from time to time.

The product information provided by Roxtec does not release the purchaser of the Roxtec system, or part thereof, from the obligation to independently

determine the suitability of the products for the intended process, installation and/or use.

Roxtec gives no guarantee for the Roxtec system or any part thereof and assumes no liability for any loss or damage whatsoever, whether direct, indirect, consequential, loss of profit or otherwise, occurred or caused by the Roxtec systems or installations containing components not manufactured by an authorized manufacturer and/or occurred or caused by the use of the Roxtec system in a manner or for an application other than for which the Roxtec system was designed or intended.

Roxtec expressly excludes any implied warranties of merchantability and fitness for a particular purpose and all other express or implied representations and warranties provided by statute or common law. User determines suitability of the Roxtec system for intended use and assumes all risk and liability in connection therewith. In no event shall Roxtec be liable for indirect, consequential, punitive, special, exemplary or incidental damages or losses.

The Roxtec products are offered and sold in accordance with the conditions of the Roxtec General Terms of Sales. The latest version of the Roxtec General Terms of Sales can be found and downloaded from roxtec.com/general-terms-of-sales.

