



Roxtec GH BG™ transit

Transit with flange and earthing terminal, for bolting onto even structures.

The Roxtec GH BG[™] is a cable and pipe seal for bonding and grounding applications. The rectangular steel frame is bolted onto steel or sandwich walls/floors and allows for high cable and pipe packing density. The transit can be used with a GE extension frame in galvanized steel to cover the depth of a thick wall. Roxtec EC (electrical continuity) test sticks are available to help indicate the electrical performance of the transit installation.

Bonding and grounding



- E/El rating according to EN 13501
- F/T rating according to UL 1479

Frame dimensions

in/lbs

The frame variants below are a limited selection. For the full range of frames and configurations, please visit roxtec.com.

IP 66/67

	. — .	Product	Frame openings	Packing space	External dimensions WxHxD	Aperture dimensions w x h	Weight	Art. no
	н	GH BG 6x1 GALV	1	4.724 x 7.087	9.941 x 13.78 x 3.661	5.827(+0.197/-0.197) x 9.646(+0.197/-0.197)	9.8	109604
		GH BG 6x2 GALV	2	4.724 × 7.087	15.079 x 13.78 x 3.661	10.945(+0.197/-0.197) x 9.646(+0.197/-0.197)	16.5	110003
		GH BG 6x3 GALV	3	4.724 × 7.087	20.217 x 13.78 x 3.661	16.102(+0.197/-0.197) x 9.646(+0.197/-0.197)	23	110015
 		GH BG 6x1 AISI316	1	4.724 × 7.087	9.941 x 13.78 x 3.661	5.827(+0.197/-0.197) x 9.646(+0.197/-0.197)	10.9	122511
		GH BG 6x2 AISI316	2	4.724 x 7.087	15.079 x 13.78 x 3.661	10.945(+0.197/-0.197) x 9.646(+0.197/-0.197)	14.7	122512
		GH BG 6x3 AISI316	3	4.724 x 7.087	20.217 x 13.78 x 3.661	16.102(+0.197/-0.197) x 9.646(+0.197/-0.197)	21.8	110477





Sealing components

Sealing components



RM BG[™] module with Multidiameter



cor

Lubricant

RM BG[™] solid npensation module



Wedge & Wedgekit



Accessories



Stayplate

Accessories ES and BG GE extension frame



BG™ sealing kit

For detailed information, please visit roxtec.com

The product information provided by Roxtec does not release the purchaser of the Roxtec system, or part thereof, from the obligation to independently determine the suitability of the products for the intended process, installation and/or use.

the intended process, installation and/or use. Roxtec gives no guarantee for the Roxtec system or any part thereof and assumes no liability for any loss or damage whatsoever, whether direct, indirect, consequential, loss of profit or otherwise, occurred or caused by the Roxtec systems or installations containing components not manufactured by an authorized manufacturer and/or occurred or caused by the use of the Roxtec system was designed or intended. Roxtec expressly excludes any implied warranties of merchantability and fitness for a particular purpose and all other express or implied representations and warranties provided by statute or common law. User determines suitability of the Roxtec system for intended use and assumes all risk and liability in connection therewith. In no event shall Roxtec be liable for indirect,

consequential, punitive, special, exemplary or incidental damages or losses. The Roxtec products are offered and sold in accordance with the conditions of the Roxtec General Terms of Sales. The latest version of the Roxtec General Terms of Sales can be downloaded from https://www.roxtec.com/en/about-us/about-roxtec/general-terms-of-sales/ We reserve the right to make changes to the product and technical information without further notice. Any errors in print or entry are no claims for indemnity. The content of this publication is the property of Roxtee International AB and is protected by copyright. This document was generated on: 2024-04-30